

Procedure for Conditioning your Nitrate Filter

- 1. Prior to Installation, soak the Nitrate (A-3) filter in a “brine” solution (salt water) for 15 minutes.**
- 2. Remove any additional filters from the canister(s) and install the Nitrate (A-3) filter into the housing (by itself). Flush this filter for 10 minutes.**
- 3. If you have a dual housing system and you are also installing an unused ceramic filter element (Ultracarb or Supercarb), install after the Nitrate filter and flush for an additional 10 minutes.**
- 4. If you have a 3 housing system, make sure you flush the additional specialty element filter (fluoride, heavy-metal, arsenic) after the Nitrate filter has been conditioned, but before the ceramic filter has been installed. Once this is done, install the ceramic filter and flush for 10 minutes.**

***NOTE: The ceramic filter is always installed into the last filter housing (from left to right) before the water is dispensed from the faucet.**